

CNV232-485PW+

RS232 to RS422 / 485 converter. Can be powered from COM port control signals

FEATURES

With CNV232-485PW + you get an RS485 or RS422 port on the PC

Selecting RS422 or RS485 with DIL switches on the

Super compact with DB9 female and screw terminals

Can be powered by external voltage from 9 - 12VDC / 500mA

Operating temperature: -40 - + 85 ° C





CNV232-485PW+

SPECIFICATIONS

