

## Converter - adapter PS/2 mini DIN 6 female to SUBD DB9 female

### FEATURES

The mouse converter only converts the plug type of the mouse and not the signal. You cannot therefore convert an RS232 serial mouse to PS/2 and the like. Converter is with thumb screws.

PS/2	DB9F
1	3
2	N/A
3	7
4	5
5	2
6	N/A

