

KNAP-HUS-GREEN-F

Plastic house for EXIT buttons, 85 x 85 x 48 mm.
Back piece for exit button. Rubber gasket, 20 mm
center hole

FEATURES

ABS plastic house for Exit button
target: 38.5 x 38.5 x 48 mm
Center hole: 20 mm
4 x mounting holes for attachment
rubber gasket included

